

# Owner's Operating Service Instruction Manual

10¢

**Model Nos.**  
**136-430A**  
**136-435A**

- **ASSEMBLY**
- **OPERATION**
- **REPAIR PARTS**

**30" RIDING MOWERS**

# IMPORTANT

It is suggested that this manual be read in its entirety before attempting to assemble or operate. Keep this manual in a safe place for future reference and for ordering replacement parts.

This unit is shipped WITHOUT GASOLINE or OIL. After assembly, see operating section of this manual for proper fuel and amount.

## SAFE OPERATION PRACTICES FOR RIDING VEHICLES

1. Know the controls and how to stop quickly—**READ THE OWNER'S MANUAL.**
2. Do not allow children to operate vehicle. Do not allow adults to operate it without proper instruction.
3. Do not carry passengers. **Keep children and pets a safe distance away.**
4. Clear work area of objects which might be picked up and thrown.
5. Disengage all attachment clutches and shift into neutral before attempting to start engine.
6. Disengage power to attachment(s) and stop engine before leaving operator position.
7. Disengage power to attachment(s) and stop engine before making any repairs or adjustments.
8. Disengage power to attachment(s) when transporting or not in use.
9. Take all possible precautions when leaving vehicle unattended such as disengaging power-take-off, lowering attachments, shifting into neutral, setting parking brake, stopping engine and removing key.
10. Do not stop or start suddenly when going uphill or downhill. Mow up and down face of steep slopes; never across the face.
11. Reduce speed on slopes and in sharp turns to prevent tipping or loss of control. Exercise extreme caution when changing direction on slopes.
12. Stay alert for holes in terrain and other hidden hazards.
13. Use care when pulling loads or using heavy equipment.
  - A. Use only approved drawbar hitch points.
  - B. Limit loads to those you can safely control.
  - C. Do not turn sharply. Use care when backing.
  - D. Use counterweight(s) or wheel weights when suggested in owner's manual.
14. Watch out for traffic when crossing or near roadways.
15. When using any attachments never direct discharge of material toward bystanders nor allow anyone near vehicle while in operation.
16. Handle gasoline with care—it is highly flammable.
  - A. Use approved gasoline container.
  - B. Never remove cap or add gasoline to a running or hot engine or fill fuel tank indoors. Wipe up spilled gasoline.
  - C. Open doors if engine is run in garage—exhaust fumes are dangerous. Do not run engine indoors.
17. Keep the vehicle and attachments in good operating condition, and keep safety devices in place. Use guards as instructed in owner's manual.
18. Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
19. Never store the equipment with gasoline in the tank inside a building where fumes may reach an open flame or spark. Allow engine to cool before storing in any enclosure.
20. To reduce fire hazard keep engine free of grass, leaves or excessive grease.
21. The vehicle and attachments should be stopped and inspected for damage after striking a foreign object, and the damage should be repaired before restarting and operating the equipment.
22. Do not change the engine governor settings or overspeed the engine.
23. When using the vehicle with mower, proceed as follows:
  - (1) Mow only in daylight or in good artificial light.
  - (2) Never make a cutting height adjustment while engine is running if operator must dismount to do so.
  - (3) Shut engine off when removing grass catcher and/or unclogging chute.
  - (4) Check blade mounting bolts for proper tightness at frequent intervals.
24. Check grass catcher bags frequently for wear or deterioration. Replace with new bags for safety protection.
25. Look behind to make sure the area is clear before placing the transmission in reverse and backing up.

# INDEX

Safe Operation Practices .....	2
Index and Assembly Instructions .....	3
Activating the Battery .....	4
Battery Warranty .....	5
Controls .....	6
Operating Instructions .....	8
Maintenance and Adjustments .....	9
Belt Removal .....	10
Lubrication .....	11
Electrical Systems .....	12
Schematic for Recoil Start .....	12
Schematic for Electric Start .....	13
Transmission Breakdown .....	14
Differential Breakdown .....	15

Troubleshooting Chart Recoil Start .....	16
Troubleshooting Chart Electric Start .....	17
Illustrated Parts Rider .....	18
Parts List for Rider .....	19
Illustrated Parts Control Linkages .....	20
Parts List for Control Linkages .....	21
Illustrated Parts Frame .....	22
Parts List for Frame .....	23
Illustrated Parts Deck and Belt System .....	24
Parts List for Deck and Belt System .....	25
Battery Box Breakdown .....	26
Deck Linkage .....	27
Parts Information .....	28

## ASSEMBLY

GRASS CATCHER Model No. 196-015A is available as optional equipment for the mowers shown in this manual.



1. The mower should not be operated without the entire grass catcher or chute deflector in place.



### NOTE

Under normal usage bag material is subject to wear, and should be checked periodically. Be sure any replacement bag complies with the mower manufacturer's recommendations.

For replacement bags, use only factory authorized replacement bag No. 764-0121.



### **IMPORTANT**

After striking a foreign object, stop the engine. Remove wire from spark plug, thoroughly inspect the mower for any damage, and repair the damage before restarting and operating the mower.



### NOTE

Reference to right-hand or left-hand side of machine is from the driver's seat facing forward.

Your mower is shipped assembled except for the steering wheel and seat (and battery on the electric start model.)

## TIRE PRESSURE

**FOR SHIPPING PURPOSES, THE TIRES ON YOUR UNIT MAY BE OVER-INFLATED. TIRE PRESSURE SHOULD BE REDUCED BEFORE UNIT IS PUT INTO OPERATION. PRESSURE SHOULD BE APPROXIMATELY 15 P.S.I. EQUAL TIRE PRESSURE SHOULD BE MAINTAINED ON ALL TIRES. MAXIMUM TIRE PRESSURE IS 30 P.S.I.**

## STEERING WHEEL ASSEMBLY See figure 1.


- Step 1. Line up the hole in the steering column and the hole in the tubing assembly and drive in the roll pin with a hammer.



### NOTE


It may be necessary to use a drift to line up the holes.

- Step 2. Slide the spacer over the tubing assembly until it lays flush against the steering box.
- Step 3. Place the steering wheel on the tubing shaft.
- Step 4. Secure in place with belleville washer and hex nut.
- Step 5. Put on steering wheel cap by hand.



**FIGURE 1. STEERING WHEEL ASSEMBLY**

Step 6. Place the seat in desired hole on seat bracket. Secure with hex nut and lock-washer. See figure 2.



**FIGURE 2. SEAT ASSEMBLY**

Step 7. Check ALL nuts and bolts for correct tightness.

## BATTERY INFORMATION FOR ELECTRIC START MODELS



**WARNING**

- A. Battery acid must be handled with great care as it will blister the skin and damage clothing. It is advisable to wear goggles, rubber gloves, and a protective apron when working with it.
- B. Neutralize acid spilled on clothing with dilute ammonia water or a water solution of baking soda. If acid gets on clothes, dilute it with clean water first, then neutralize.
- C. If for any reason acid should be spattered in the eyes, wash it out immediately with clean cold water. Seek medical aid if discomfort continues.
- D. Since battery acid is corrosive to metals, do not pour into any sink or drain. Rinse empty electrolyte containers and mutilate before discarding.



**DANGER**

**BATTERIES CONTAIN SULFURIC ACID AND MAY CONTAIN EXPLOSIVE GASES (when electrolyte has been added)**

- A. Keep sparks, flame, cigarettes away.
- B. Hydrogen gas is generated during charging and discharging.
- C. Ventilate when charging or using in enclosed space.
- D. When using a charger—to avoid sparks, NEVER connect or disconnect charger clips to battery while charger is turned on.
- E. Always shield eyes, protect skin and clothing when working near batteries.

### A. Activating the Battery

1. Place battery to be filled on bench or work-bench. NEVER activate battery in unit. Remove vent caps from all cells.
2. Fill each cell carefully using battery grade 1.250-1.265 specific gravity. Sulfuric acid to be 3/8" above the top of the separators or to the split ring.
3. Allow battery to set for 20 minutes to 1/2 hour. Add additional acid if necessary to bring it up to the proper level.
4. Replace the vent caps.

5. The battery can now be charged after the 20 minutes setting period. Battery can be SLOW CHARGED (DO NOT FAST CHARGE) at a maximum bench rate of 4-5 amperes until the specific gravity reading is 1.265-1.275. A charging rate in excess of this will buckle and warp the positive plates and perforate the separators. If electrolyte bubbles violently while charging, reduce charging rate until excessive bubbling action subsides, then continue charging until specific gravity is reached.



#### **CAUTION**

After the battery has been in service, add only approved water. DO NOT ADD ACID.

#### **B. To Install Battery**

To install the battery in this unit, refer to next column.

#### **C. Maintenance**

1. Check periodically (every two weeks or before and after charging) to be sure electrolyte level is 9/16" above separator plates. Add only distilled water or good quality drinking water. NEVER add additional acid or other chemicals to battery after initial activation.
2. The battery should be checked with a hydrometer after every 25 hours of operation. If the specific gravity is less than 1.225 remove battery and recharge.
3. Coat the terminals and exposed wiring with a thin coat of grease or petroleum jelly for longer service and protection against electrolyte corrosion.
4. The battery should be kept clean. Any deposits of acid should be neutralized with soda and water. Be careful not to get this solution in the cells.

#### **D. Storage**

1. Charge battery using normal methods. NEVER store discharged battery as it will not recover.
2. Store in cold, dry place.
3. Recharge battery whenever the specific gravity is less than 1.225 before returning to service or every two months, whichever occurs first.

#### **E. Common Causes For Battery Failure Are:**

1. Overcharging
2. Undercharging
3. Lack of water
4. Loose hold downs and/or corroded connections
5. Excessive loads
6. Battery electrolyte substitutes
7. Freezing of electrolyte



#### **NOTE**

THESE FAILURES DO NOT CONSTITUTE WARRANTY.

#### **LIMITED WARRANTY**


For ninety (90) days of original retail purchase, the battery carries a limited warranty against faulty material or workmanship by the battery manufacturer.

#### **INSTALLING THE BATTERY (Electric Start Models Only)**

See figure 3.

Step 1. Tip the seat bracket forward to expose the battery box.

Step 2. Remove screw (A) and lockwasher (B).



**FIGURE 3. INSTALLING THE BATTERY**

Step 3. Lift out the battery box bracket.

Step 4. Place the battery in the battery box with the positive terminal (+) to the front of the riding mower.

- Step 5. Attach the large red wire from the solenoid and the small red wire to the positive ( + ) terminal of the battery with a 1/4" screw (E), washer (D) and nut (C).
- Step 6. Attach the large red wire from the ground (-) to the negative (-) terminal of the battery with a 1/4" screw (E), washer (D) and nut (C).
- Step 7. Replace the battery box bracket with screw (A) and washer (B). See figure 3.

### **CONTROLS See figure 5.**

This manual should be read in its entirety before you operate your Riding Mower. The more you know and understand about the machine and its operation, the better job it will do for you. While reading the manual, compare the illustrations with your mower to familiarize yourself with the locations of various controls, lubrication points, attachments and adjustment features.

### **IGNITION KEY**

**Recoil Model.** The key must be turned to the ON position before the recoil handle is pulled to start the engine. Remove the key when the mower is not in use. Turn the key to the left (to the OFF position) to stop the engine.

### **LIFT AND DISENGAGEMENT LEVER**

The lift and disengagement lever is used to raise and lower the cutting deck, set the cutting height, and disengage the cutting blades.

Move the lever to the left and pull the lever all the way back and lock it to disengage the blades. The lever may be set in any one of the five cutting height positions. This lever works in conjunction with the deck wheel adjusters.

**Electric Model.** The key must be turned to the START position to start the engine. After the engine is running let the key return to the ON position. Remove the key when the mower is not in use. Turn the key to the OFF position to stop the engine.

Study the operating instructions and safety precautions thoroughly to insure proper functioning of your mower and to prevent injury to yourself and others. Be sure to save this manual for future reference.

### **THROTTLE CONTROL**

The throttle control is used to regulate the engine speed and to activate the choke on the engine. To get the maximum efficiency on cutting, the throttle should be in the FAST position when operating the mower. Pushing the throttle all the way forward, past FAST will choke the engine.

### **INTERLOCKS (Not Shown)**

An interlock safety switch is located on the clutch pedal and the lift and disengagement lever.

The clutch pedal must be depressed all the way down (the speed control handle can be pulled back to lock it down) and the lift and disengagement lever must be in the STOP position (all the way back) before the engine can be started. Failure to follow these instructions will prevent starting.

On the recoil start model, the ignition will be grounded. On the electric start model, the starter will not run.

### **GEAR SHIFT LEVER**

The gear shift lever has three positions, FORWARD, NEUTRAL and REVERSE. The clutch pedal must be depressed and the riding mower must not be moving when shifting gears. Shifting gears may be difficult when the speed control handle is all the way back. Do not force the shift lever. Release the clutch pedal slightly to line up the shifting collar in the transmission. Then try to shift the gears.

### **BRAKE**

To operate the brake depress the right pedal all the way down. To lock the brake in the park position, pivot the pedal forward with your foot as you depress it. It will stay in the depressed position. To release the parking brake, pivot the pedal to the rear.

### **DECK WHEEL ADJUSTERS**

Always set both deck wheels in the same relative position. Set these wheels after the Lift and Disengagement Lever is set. The wheels should just clear the ground. This will prevent scalping the grass.

## CLUTCH PEDAL

The clutch pedal on the left side when depressed reduces the ground speed. It disengages the engine from the transmission when depressed all the way down. It can be held in the disengaged position by pulling the Speed Control Lever into the locked position (all the way back). To stop the mower, depress the Clutch and Brake Pedals.

## SPEED CONTROL LEVER. See figures 4 and 5.

The Speed Control Lever can be used as a hand control for the clutch pedal. It is also used to lock the clutch pedal in the disengaged position by pulling it all the way back towards the operator and locked to the right.

The control lever allows you to regulate the maximum ground speed of the riding mower by setting the control lever in any one of four settings.



The further forward the control lever is set, the faster the ground speed.




FIGURE 4. SPEED CONTROL LEVER

## STOPPING

**Engine**—Turn the ignition key to the left to the OFF position.

**Rider**—Depress the clutch and brake pedals.

**Blades**—Pull the lift and disengagement lever all the way back and lock it.




FIGURE 5.

## OPERATING INSTRUCTIONS



### **CAUTION**

1. Keep all shields and guards in place.
2. Before leaving operator's position:
  - Shift controls into neutral
  - Set parking brake
  - Disengage attachment drive
  - Shut off engine
  - Remove ignition key
3. Wait for all movement to stop before servicing machine.
4. Keep people and pets a safe distance away from machine.



### **CAUTION**

Parking Brake **MUST** be disengaged before unit is put into motion.



### **NOTE**

Unit is equipped with separate brake and clutch pedals. To efficiently stop, it is necessary to disengage the clutch when applying the brakes.


## STARTING THE ENGINE

1. Be sure the crankcase is filled with oil as recommended in the engine manual. Put regular gasoline in the gasoline tank.
2. Be sure the fuel shut off valve located on the carburetor is open.
3. Attach the wire to the spark plug.
4. Depress the clutch pedal and lock it down with the speed control lever.
5. Pull the lift and disengagement lever all the way back to the disengaged position and lock it.
6. Set the throttle control lever in the **CHOKE** position.
7. **Recoil Model.** Turn the ignition key to the **ON** position. Twist the recoil starter handle until it is free and pull it with a quick steady motion. After the engine starts, return the recoil starter handle. Twist it until it locks. See figure 6.



### **NOTE**

If these instructions are not followed the engine will stop running when you engage the clutch or blades are engaged.



**FIGURE 6. RECOIL STARTER**

**Electric Start Model.** Turn the ignition key to the **START** position. When the engine starts let the key return to the **ON** position.

Slowly return the throttle to the running position as soon as the engine starts.

8. To stop either model, turn the ignition key to the **OFF** position. Remove the key when the rider is not in use.

## PUTTING THE RIDING MOWER IN MOTION

1. Advance the throttle control from  $\frac{3}{4}$  to full throttle to prevent strain on the engine and to operate the cutting blades.
2. Set the stop lever in the slowest position.
3. Hold the clutch pedal down with your left foot and release the speed control lever.
4. Place the gear shift lever in either the **FORWARD** or **REVERSE** position.
5. Slowly release the clutch pedal.
6. To stop, depress the clutch and the brake pedals.
7. The blades can be engaged while moving or while standing still. Move the lift and disengagement lever forward slowly until the blades are running.



After learning to control the machine at slow speeds, set the stop lever in a faster position. The unit will maintain the highest speed set without touching the controls. To slow down, depress the clutch pedal until the speed desired is obtained. When the clutch pedal is released, the riding mower will operate at the highest speed set on the stop lever.

## MAINTENANCE AND ADJUSTMENTS


### THROTTLE CONTROL

#### To Check Operation:

1. Remove air cleaner.
2. Move throttle control lever to CHOKE position. The carburetor choke should be closed.
3. Move throttle control lever to STOP position. Lever should make good contact with stop switch.

#### To Adjust: See figure 7.

Place throttle control lever in FAST (high speed) position. Loosen control casing clamp screw "B". Move control casing "A" and wire until lever "D" touches choke operating link at "C". Tighten casing clamp screw "B". Replace air cleaner.



**FIGURE 7. THROTTLE ADJUSTMENT  
CARBURETOR ADJUSTMENT**

Carburetors are adjusted at the factory and normally do not need adjustment unless they have been disassembled.

#### Initial Adjustment After Re-assembly. See figure 8.

Turn needle valve clockwise until it just closes.




#### **CAUTION**

Valve may be damaged by turning it too far. Now open needle valve 1-1/8 turns counterclockwise. Close idle valve in same manner and open 1-1/8 turns. This initial adjustment will permit the engine to be started and warmed up prior to final adjustment.

#### Final Adjustment. See figure 8.

Turn needle valve in until engine misses (lean mixture). Then turn it out past smooth operating point until engine runs unevenly (rich mixture). Now turn needle valve to the mid-point between rich and lean so the engine runs smoothly.

Hold throttle at idle position and set idle speed adjusting screw until fast idle is obtained (1750 RPM). Hold throttle in idle position and turn idle valve in (lean) and out (rich) until engine idles smoothly. Then reset idle speed adjusting screw so that engine idles at 1750 RPM. Release throttle—engine should accelerate without hesitation or sputtering. If engine does not accelerate properly the carburetor should be re-adjusted to a slightly richer mixture.



**FIGURE 8. CARBURETOR ADJUSTMENT**

### CHAIN ADJUSTMENT

After the first five hours of operation the initial slack should be removed from the chain. The chain should be tight enough so that it deflects approximately 1/2" when it is depressed with the thumb.

#### To Adjust:

The adjusting bolt is located under the frame, above the cutting deck on the right side of the mower.

Turn the adjusting bolt clockwise with an open end wrench until the chain reaches the proper tension.




#### **NOTE**

If the transmission mounting plate will not slide forward to adjust the chain tension, it may be necessary to loosen the four nuts mounting the transmission to the frame.

To adjust the brake, tighten the locknut one half turn and then test the brakes. Repeat if necessary.

The brake is located by the right rear wheel inside the frame.



**FIGURE 9. BRAKE ADJUSTMENT**

### BLADES




**WARNING**

Disconnect the spark plug wire and remove the ignition key before removing the blades.

Sharp and balanced blades are essential for efficient mowing and long mower and engine life. When sharpening blades, file equal amounts of metal from each side. The blades should be balanced before they are reinstalled. An unbalanced blade will cause excessive vibration and undue wear on the mower and the engine. When reassembling, all parts must be installed in the proper order and fastened securely.

Remove the 3/8" bolt and lockwasher. Pull the blade and adapter off the mower deck. To remove the adapter from the blade, remove the two 5/16" bolts, lockwashers and nuts. See figure 11.



**FIGURE 10. BLADE REMOVAL**

### MOWER DECK

The underside of the mower deck should be cleaned after each period of use as grass clippings, leaves, dirt and other matter will accumulate. This accumulation of grass clippings, etc., is undesirable as it will invite rust and corrosion and may cause an uneven discharge of grass clippings at the next mowing.

The deck may be cleaned by tilting the mower on its left side. Scrape clean with a suitable tool or by washing with a stream of water from a garden hose. Be sure to disconnect the spark plug wire and ground it while performing this maintenance.

### PREPARING FOR BELT REMOVAL

1. To prevent gasoline from leaking from the engine, remove the fuel tank cap, place a piece of thin plastic over the neck of the fuel tank and screw on the cap.
2. Disconnect the spark plug wire and ground it against the engine.



**NOTE**

If the unit is equipped with a battery, continue with step 3.

3. Remove the battery to prevent acid from leaking.



**WARNING**

Disconnect the negative terminal first and connect last when installing the battery.

### BELT REMOVAL. See figure 11.

To remove either or both belts:

1. Place the speed control lever in the locked position.
2. Move the lift and disengagement lever into the disengaged position.
3. Remove the two rear hex nuts on the engine bolts to remove the engine belt guard and slide the guard away from the chain to remove it.
4. Lower the cutting deck to its lowest position.
5. Remove the blade drive belt from the engine pulley.



**NOTE**

The blade drive belt need not be removed. Go to Step 8.

6. Remove the deck belt guards.
7. Remove and replace the belt.

### To remove the variable speed belts:

8. Remove the variable speed pulley by removing the center hex nut and lockwasher.
9. Remove the transmission pulley by removing the hex nut and washer.
10. The belts can now be removed.




FIGURE 11. BELT REMOVAL

## LUBRICATION

1. **Engine.** Maintain the engine oil according to the engine manual.
2. **Bearings.** The following bearings are oil impregnated and do not require lubrication, however, their normal life can be extended by lubricating them once a season with a light, non-detergent oil.
  - A. King Pin Bearings (total 4 bearings)
  - B. Rear Axle Bearings (total 3 bearings)
  - C. Front Wheel Bearings (total 4 bearings)
  - D. Deck Wheel Bearings (total 4 bearings)
3. **Throttle Control and Cable.** Wipe oiled rag along entire length of cable.


4. **Chain.** Wipe oiled rag along entire length of chain.



Under extremely dusty conditions do not oil the chain.

5. **Linkage.** Oil all deck linkage and height adjustment linkage.
6. **Transmission.** Lubricated at the factory, does not require checking. Lubricate with 5 oz. of grease, high temp. 450°F, if disassembled.
7. **Differential.** Lubricated at the factory, does not require checking. Lubricate with 2 oz. of grease, high temp. 450°F if disassembled. If ordered from the factory use Part No. 737-0120.

# 136-430A




## SCHEMATIC FOR ELECTRICAL SYSTEM

## PARTS LIST FOR SCHEMATIC MODEL 136-430A

REF. NO.	PART NO.	DESCRIPTION	NEW PART
1	725-0269	Safety Switch Norm Closed-Red	
2	725-0266	Magneto Ignition Switch w/Nut	
3	725-0281	Wire Harness	
4	712-0121	Hex Nut #10-24	
5	710-0425	Truss Mach. Scr. #10-24 x .62	
6	736-0338	Fiber Washer	
7	732-0257	Switch Spring	
8	736-0225	Internal L-Wash, 5/8 I.D.	

# 136-435A




**SCHEMATIC FOR ELECTRIC START MODEL**

## **PARTS LIST OF SCHEMATIC FOR MODEL 136-435A**

REF. NO.	PART NO.	DESCRIPTION	NEW PART
1	725-0117	Battery	
2	725-0270	Solenoid	
3	725-0267	Key Switch	
4	725-0268	Safety Switch—Black	
5	725-0122	Electric Wire	
6	725-0150	Electric Wire	
7	725-0280	Wire Harness	

# 136-430A 136-435A




## SINGLE SPEED TRANSMISSION PART NO. 717-0223

### PARTS LIST FOR TRANSMISSION USED ON MODELS 136-430A AND 136-435A

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART	REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	716-0104		Snap Ring		13	710-0195		Hex Hd. Cap Scr. 1/4-28 x .62*	
2	748-0852		Sprocket 8T #41		14	741-0862		Detent Ball	
3	714-0129		Key Hi-Pro #4		15	732-0863		Detent Spring	
4	711-0854		Shaft Output		16	736-0116		Washer	
5	714-0126		Key Hi-Pro #606 (Hardened)		17	716-0106		E-ring	
6	717-0123		Housing Half		18	716-0865		Snap Ring #3100-50	
7	748-0855		Bearing		19	748-0866		Bevel Pinion	
8	712-0117		Locknut 1/4-28 Thd.*		20	748-0867		Bearing	
9	748-0856		Bevel Gear		21	738-0159		Pinion Shaft	
10	748-0857		Clutch Collar		22	736-0192		Washer	
11	08583		Detent Shaft Assembly		23	736-0921		Lockwasher 1/2"	
12	717-0124		Housing Half with Detent Hole		24	712-0922		Hex Jam Nut 1/2-20 Thd.*	
					25	737-0120		Grease High Temp. 450°F. (5 oz.)	

\*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally order by part number and size as shown on parts list.



**PARTS LIST FOR DIFFERENTIAL ASSEMBY PART NUMBER 717-0328**

Ref. No.	Part No.	Qty. Req'd.	Description	New Part
1	715-0247	2	Spring Pin Spir. 3/16" Dia. x 1.00" Lg.	
2	748-0185	2	Gear—Double "O" Hole	N
3	738-0300	1	Shaft—Long 19.31" Lg.	
4	736-0188	2	Fl-Wash. .760 I.D. x 1.49 O.D.	
5	717-0341	2	Housing Half	N
6	736-0119	2	L-Wash. 5/16" Scr.*	
7	710-0363	2	Hex Scr. 5/16-24 x 4.00" Lg.*	
8	736-0187	2	Fl-Wash. .640 I.D. x 1.24 O.D.	
9	748-0158	2	Gear—Round Hole	
10	711-0276	1	Drive Pin	
11	712-0237	2	Hex Cent. L-Nut 5/16-24 Thd.	
12	09054	1	Sprocket—40 Tooth	
13	738-0301	1	Shaft—Short 7.07" Lg.	N

\*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

# TROUBLE SHOOTING CHART FOR RECOIL START MODELS

CAUTION: ALWAYS DISCONNECT SPARK PLUG BEFORE ATTEMPTING ANY REMEDY.

TROUBLE	LOOK FOR	REMEDY
Engine fails to start.	Safety System	<p>If the engine will not start be sure the clutch control is disengaged; blade controls disengaged, the throttle control is set and the key is turned on.</p> <p>A. Disconnect the yellow wire from the engine. This comes from the ignition switch.</p> <p>B. If the engine fails to start the problem is with the engine, not the safety system.</p> <p>C. If the engine starts, the problem is with the safety system. Check the yellow wire for a ground.</p> <p>D. Check the operation of the switch behind the recoil starter handle.</p> <p>E. If the engine stops when the clutch or blade is engaged, the recoil handle is not pushed into the receptacle and twisted a quarter turn.</p>
	Blocked fuel line or empty gas tank.	Clean fuel line; check fuel supply. Also check fuel shut-off valve.
	Defective spark plug.	<p>Spark plug lead wire disconnected.</p> <p>Faulty spark plug—spark should jump gap between control electrode and side electrode. If spark does not jump, replace spark plug.</p> <p>NOTE: Use insulated pliers to hold the spark plug wire.</p>
	Throttle setting.	Throttle control lever not in the starting position.
	Loose connections	Spark plug wire loose.
Hard starting or loss of power.	Dirty air cleaner.	Remove air cleaner and clean as outlined in <b>Engine Manual</b> .
	Carburetor improperly adjusted.	Review paragraph <b>Carburetor Adjustment</b> .
Excessive vibration.	Bent or damaged blade spindle.	Stop engine immediately; tighten all bolts and make all necessary repairs. If vibration continues, have the unit serviced by a competent repairman.
Unit fails to discharge grass.	Discharge chute clogged.	Clean discharge chute and inside of deck.
	Foreign object lodged in deck.	Remove object from deck. See CAUTION following step 1 in paragraph <b>Operation</b> .
Engine overheats.	Obstructions in air passages.	Remove any obstruction from air passages in shroud.
	Grass and dirt in engine shroud.	Clean cooling fins.
	Oil level.	Fill crankcase to proper oil level.




# TROUBLE SHOOTING CHART FOR ELECTRIC START MODELS

TROUBLE	LOOK FOR	REMEDY
Engine fails to start.	Safety System	<p>A. Check for a blown fuse in the wire leading from the positive terminal of the battery.</p> <p>B. Before checking the safety system further, be sure the clutch control and the blade control are disengaged; only the starting system is being checked. Therefore remove the spark plug lead and ground it to prevent the engine from starting.</p> <p>C. Attach a wire (minimum 18 gauge) to the positive terminal of the battery and touch the other end to the small terminal (coil primary) of the solenoid. If the engine cranks, the problem is in the safety system.</p> <p>D. Check for continuity from the battery to the solenoid. NOTE: The positive terminal of the battery should have a large cable (#8 gauge) and a small wire (#18 gauge) attached to it.</p> <p>E. Check all wires and cable for tightness.</p> <p>F. Use a #8 gauge wire and jump between the two large terminals of the solenoid. If the unit starts, replace the solenoid.</p> <p>G. If the unit fails to start after following the above procedure the problem is probably in the starting motor of the engine.</p>
	Blocked fuel line or empty gas tank.	Clean fuel line; check fuel supply. Also check fuel shut-off valve.
	Defective spark plug.	<p>Spark plug lead wire disconnected.</p> <p>Faulty spark plug—spark should jump gap between control electrode and side electrode. If spark does not jump, replace spark plug.</p> <p>NOTE: Use insulated pliers to hold the spark plug wire.</p>
	Throttle setting.	Throttle control lever not in the starting position.
	Loose connections	Spark plug wire loose.
Hard starting or loss of power.	Dirty air cleaner.	Remove air cleaner and clean as outlined in <b>Engine Manual</b> .
	Carburetor improperly adjusted.	Review paragraph <b>Carburetor Adjustment</b> .
Excessive vibration.	Bent or damaged blade spindle.	Stop engine immediately; tighten all bolts and make all necessary repairs. If vibration continues, have the unit serviced by a competent repairman.
Unit fails to discharge grass.	Discharge chute clogged.	Clean discharge chute and inside of deck.
	Foreign object lodged in deck.	Remove object from deck. See CAUTION following step 1 in paragraph <b>Operation</b> .
Engine overheats.	Obstructions in air passages.	Remove any obstruction from air passages in shroud.
	Grass and dirt in engine shroud.	Clean cooling fins.
	Oil level.	Fill crankcase to proper oil level.

# 136-430A 136-435A

IF YOU WRITE TO US ABOUT THIS ARTICLE  
OR IF YOU ORDER REPLACEMENT PARTS AL-  
WAYS MENTION THIS MODEL & SERIAL NO  
MODEL



**PARTS LIST FOR MODEL 136-430A AND 136-435A**

Ref. No.	Part No.	Color Code	Description	New Part	Ref. No.	Part No.	Color Code	Description	New Part
1	757-0264		Seat Ass'y.—Comp.	N	40	736-0921		L-Wash. 1/2" Scr.*	
2	731-0219		Steering Wheel 12" Dia.		41	712-0206		Hex Nut 1/2-13 Thd.*	
3	731-0220		Steering Wheel Cap		42	736-0119		L-Wash. 5/16" Scr.*	
4	712-0158		Hex Cent. L-Nut 5/16-18 Thd.		43	712-0267		Hex Nut 5/16-18 Thd.*	
5	736-0219		Belleville Wash. .400 I.D. x 1.13		44	11168		Lift Bracket	
6	750-0316		Steering Tube	N	45	736-0329		L-Wash. 1/4" Scr.*	
7	710-0224		Hex AB-Tap Scr. #10 x .50" Lg.		46	712-0287		Hex Nut 1/4-20 Thd.*	
8	746-0177		Throttle Control 53.0" Lg.		47	710-0289		Hex Scr. 1/4-20 Thd.*	
9	715-0114		Spring Pin Spir. 1/4" Dia. x 1.50" Lg.		48	736-0242		Belleville Wash. .345 I.D. x .88 O.D.	
10	748-0227		Hex Flange Brg. .630 I.D.		49	710-0627		Hex Scr. w/lock 5/16-24 x .75" Lg.	
11	12812		Steering Shaft Ass'y.	N	50	734-0517		Rear Wheel Rim Ass'y. w/hub	
12	735-0117		Floor Mat		51	734-0523		Rear Wheel Ass'y.—Comp.	
13	10810 —462		Fender—L.H.		52	734-0298		Tire Only 13 x 5.00 Tubeless	N
14	712-0287		Hex Nut 1/4-20 Thd.*		53	741-0199		Flange Brg.—Plastic—	
15	736-0329		L-Wash. 1/4" Scr.*		54	10809 —462		Fender—R.H.	
16	710-0134		Carriage Bolt 1/4-20 x .62" Lg.*			713-0357		#41 Chain 1/2" Pitch x 67 Links	
17	748-0227		Hex Flange Brg. .630 I.D.			713-0723		#41 Master Link 1/2" Pitch Type II	
18	711-0198		Pivot Bushing (Tie Rod End)		55	10824 —462		Eng. Box—Side Panel R.H.	
19	09709 —462		Front Wheel Axle Ass'y.—L.H.		56	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
20	11376 —462		Front Pivot Bracket		57	10470		Bearing Plate	
21	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*		58	10471		Rear Axle Sup. Brkt. Ass'y.	
22	712-0923		Hex Cent. L-Nut 5/8-18 Thd.		59	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*	
23	736-0158		L-Wash 5/8" Scr.*		60	712-0267		Hex Nut 5/16-18 Thd.*	
24	09711 —462		Pivot Bar Ass'y.		61	736-0119		L-Wash. 5/16" Scr.*	
25	710-0312		Hex Hd. Cap Scr. 5/8-18 x 1.31" Lg.		62	10827 —462		Eng. Box—Top Panel	
26	711-0335		Tie Rod		63	720-0165		Ball Knob—Black 3/8-16 Thd.	
27	09706 —462		Front Wheel Axle Ass'y.—R.H.		64	720-0143		Grip—Black—Lift Handle	
28	734-0484		Tire 10.5 x 3.50 Only—Front Wheel		65	10826 —462		Eng. Box—Front Panel	
29	734-0483		Front Wheel Ass'y.—Comp. 10.5 x 3.50		66	10846		Shift Lever Ass'y.	
30	711-0169		Collar 5/8" I.D.		67	10060 —462		Seat Bracket	
31	710-0494		Sq. Hd. Set Scr. 5/16-18 x .38" Lg.		68	10825 —462		Engine Box Side Panel—L.H.	
32	710-0134		Carriage Bolt 1/4-20 x .62" Lg.*		69	750-0296		Steering Wheel Adapter Ass'y.	N
33	10806 —462		Fender Brace		70	11053		Switch Brkt. Ass'y. (430A)	
34	714-0507		Cotter Pin 3/32" Dia. x 1.00" Lg.*		71	710-0224		Hex AB-Tap Scr. #10 x .50" Lg.	
35	736-0329		L-Wash. 1/4" Scr.*		72	11528 —462		Eng. Box Top Bezel (430A)	
36	712-0287		Hex Nut 1/4-20 Thd.*			11527 —462		Eng. Box Top Bezel (435A)	
37	710-0252		Hex Scr. 1/4-20 x .75" Lg.*		73	712-0121		Hex Nut #10-24 Thd. (430A)	
38	712-0287		Hex Nut 1/4-20 Thd.*		74	732-0257		Switch Spring (430A)	
39	726-0221		Push Cap 1/2" Dia.		75	736-0338		Fiber Wash. (430A)	
					76	710-0425		Truss Mach. Scr. #10-24 x .62" Lg. (430A)	
					77	710-0351		Truss Mach Scr. #10 x .50" Lg. (430A)	
					78	11263		Handle—Plastic (430A)	

\*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

(462—Red Flake)

When ordering parts, if color or finish is important use the appropriate color code shown above (e.g. Red Flake finish—10057 (462)).


**NOTE:** This instruction manual covers various models and all accessories shown do not necessarily apply to your model mower.

**NOTE:** The engine is not under warranty by the mower manufacturer . . . If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines—Gasoline."



# 136-430A

# 136-435A




**PARTS LIST FOR MODEL 136-430A AND 136-435A**

Ref. No.	Part No.	Color Code	Description	NEW PART	Ref. No.	Part No.	Color Code	Description	NEW PART
1	731-0347		Steering Box Top Cover	N	30	11825		Index Bracket	
2	12819		Steering Support Brkt.	N	31	725-0268		Safety Switch (435A)	
3	710-0224		Hex AB-Tap Scr. #10 x .50" Lg.*			725-0269		Safety Switch (430A)	
4	10818 —462		Front Cover Steering Box		32	736-0329		L-Wash. 1/4" Scr.*	
5	712-0267		Hex Nut 5/16-18 Thd.*		33	712-0287		Hex Nut 1/4-20 Thd.*	
6	736-0119		L-Wash. 5/16" Scr.*		34	710-0559		Hex Scr. 1/4-28 x 1.75" Lg.*	
7	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*		35	732-0231		Torsion Spring	
8	710-0352		Hex Tap Scr. 1/4" x .38" Lg.*		36	736-0169		L-Wash. 3/8" Scr.*	
9	11375 —462		Steering Box		37	712-0798		Hex Nut 3/8-16 Thd.*	
10	710-0224		Hex AB-Tap Scr. #10 x .50" Lg.*		38	11826		Lift Handle	
11	712-0214		Hex Cent. L-Nut 3/8-24 Thd.		39	720-0143		Grip	
12	736-0185		Fl-Wash. .406 I.D. x .74 O.D.		40	712-0117		Hex Cent. L-Nut 1/4-28 Thd.*	
13	712-0267		Hex Nut 5/16-18 Thd.*		41	715-0107		Spring Pin Spirol 5/16" Dia. x 1.38" Lg.	
14	736-0119		L-Wash. 5/16" Scr.*		42	11830		Lift Shaft Ass'y.	
15	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*		43	710-0260		Carriage Bolt 5/16-18 x .62" Lg.*	
16	712-0798		Hex Nut 3/8-16 Thd.*		44	712-0267		Hex Nut 5/16-18 Thd.*	
17	736-0169		L-Wash. 3/8" Scr.*		45	736-0119		L-Wash. 5/16" Scr.*	
18	10832		Brake Lever Bracket		46	738-0140		Shld. Scr. .437" Dia. x .180	
19	720-0165		Ball Knob—Black		47	09721		Pivot Link Ass'y.	
20	12817		Shift Lever Handle Ass'y.	N	48	711-0332		Lift Brkt Pin	
21	736-0160		Fl-Wash. .530 I.D. x .930 O.D.		49	12337		Deck Link Ass'y.	
22	738-0234		Shld. Scr. .500" Dia. x .295		50	736-0192		Fl-Wash. .531 I.D. x .93 O.D.	
23	736-0235		Fl-Wash. .406 I.D. x 1.25 O.D.		51	714-0101		Int. Cotter Pin 1/2" Dia.	
24	712-0116		Hex Ins. L-Nut 3/8-24 Thd.		52	09735		Conn. rod 3/16 x 1.0 x 12.5" Lg.	
25	12825		Lock Link Ass'y.	N	53	12337		Deck Link Ass'y.	
26	12378		Brake Pedal Pad		54	09737		Link Slotted	
	12379		Clutch Pedal Pad (not shown)		55	11831		Lift Hub Ass'y.	
27	11379		Clutch Foot Pedal Rod Ass'y.		56	11827		Handle Lift Brkt. Ass'y.	
28	738-0213		Shld. Scr. .498" Dia. x 1.450		57	750-0195		Roller—Spacer .505 I.D. x .628	
29	710-0258		Hex Scr. 1/4-20 x .62" Lg.*		58	738-0234		Shld. Scr. .500" Dia. x .295	
					59	736-0119		L-Wash. 5/16" Scr.*	
					60	712-0267		Hex Nut 5/16-18 Thd.*	
					61	735-0185		Rubber Wash. .500 I.D.	N

# 136-430A 136-435A

NOTE: If for any reason Disc Brake is d.sassembled, be sure round end of push pins (Ref. No. 59) is toward the cam lever (Ref. No. 60)



FRAME VIEW

# **PARTS LIST FOR MODELS 136-430A AND 136-435A**

Ref. No.	Part No.	Color Code	Description	New Part	Ref. No.	Part No.	Color Code	Description	New Part
1	—		Engine		36	747-0109		Brake Rod .25" Dia. x 31.62"	
2	10804		Engine Brace Ass'y.		37	761-0130		Disc. Brake Ass'y. —Comp.	
3	09785		Vari. Spd. Brkt. Ass'y.		38	732-0118		Extension Spring (Brake)	
	10599		Vari. Spd. Pulley & Brkt. Ass'y. —Comp.		39	10245 —462		Disc Brake Brkt. Ass'y.	
4	712-0267		Hex Nut 5/16-18 Thd.*		40	710-0198		Hex Sems Scr. 5/16-18 x .75"	
5	736-0119		L-Wash. 5/16" Scr.*		41	714-0129		#4 Hi-Pro Key 3/32 x 5/8" Dia. Hardened	
6	10173		Var. Spd. Guide Brkt. Assy.		42	732-0192		Spring .88 O.D. x 3.75 (Var. Drive)	
7	10080		Vari. Spd. Rod		43	710-0322		Hex Sems Scr. 5/16-18 x 1.00" Lg.*	
8	710-0134		Carriage Bolt 1/4-20 x .62"		44	715-0119		Spring Pin Spir. 5/32" Dia. x .75" Lg.	
9	761-0157		Blade Brake Ass'y.		45	714-0365		#6 Hi-Pro Key 5/32 x 5/8" Dia.	
10	732-0191		Spring .75 O.D. x 11.0" Lg. (Variable Spd. Pedal)		46	710-0442		Hex Hd. Cap Scr. 5/16-18 x 1.50" Lg. H.T.	
11	732-0191		Spring .75 O.D. x 11.0" Lg. (Variable Spd. Pedal)		47	10247 —462		Transmission Plate	
12	10801 —462		Fender Brace		48	717-0223		Transmission Ass'y. —Comp.	
13	712-0287		Hex Nut 1/4-20 Thd.*		49	10404		Engine Brace	
14	710-0136		Hex Hd. Cap Scr. 1/4-20 x 1.75"		50	712-0429		Hex Ins. L-Nut 5/16-18 Thd.	
15	10057 —462		Frame		51	710-0378		Hex Hd. Cap Scr. 5/16-18 x 2.50" Lg.*	
16	11379 —462		Clutch Foot Pedal Rod Ass'y.		52	761-0133		Spacer for Disc Brake .322 I.D. x .38	
17	10057 —462		Frame		53	712-0158		Hex Center L-Nut 5/16-18 Thd.*	
18	715-0131		Spring Pin Roll 1/4" Dia. x 2.50"		54	HH-12-03293		Casting Carrier Side	
19	10848 —462		Foot Pedal Latch Ass'y.		55	HH-15-03149		Friction Pad 1.110" Dia. x .245 Thk.	
20	11378		Brake Foot Pedal Rod		56	HH-03-03303		Friction Pad 1.110" Dia. x .472 Thk.	
21	732-0245		Brake Spring		57	HH-03-03303		Back-up Disc	
22	715-0103		Sprg. Pin Spir. 1/8" Dia. x .75"		58	HH-12-03292		Casting Cam Side	
23	736-0329		L-Wash. 1/4" Scr.*		59	HH-05-03034		Push Pin	
24	712-0287		Hex Nut 1/4-20 Thd.*		60	HH-18-03493		Cam Lever	
25	10078		Foot Pedal Rod—18.80" Lg.		61	HH-03-03032		Washer	
26	711-0404		Shoulder Nut		62	HH-02-03631		Hex Locknut	
27	712-0429		Hex Cent. L-Nut 5/16-18 Thd.		63	HH-06-03031		Spring	
28	11382 —462		Clutch Bar Rod		66	737-0104		Sq. Hd. Pipe Plug 1/4" (For Eng. Oil Drain—Not Shown)	
29	710-0322		Hex Sems Scr. 5/16-18 x 1.00"*		67	737-0114		Pipe Nipple 3/8-1/4 x 3.0" Lg. (For Eng. Oil Drain—Not Shown)	
30	710-0198		Hex Sems Scr. 5/16-18 x .75"*						
31	712-0267		Hex Nut 5/16-18 Thd.*						
32	710-0117		Hex Hd. Cap Scr. 5/16-24 x 1.00" Lg. H.T.						
33	09780 —462		Trans. Belt Guard Ass'y.						
34	711-0404		Shoulder Nut						
35	712-0429		Hex Ins. L-Nut 5/16-18 Thd.						


# 136-430A 136-435A



## IMPORTANT

Belts listed by Part Number are of special construction and should be used when replacement is necessary. The dimensions and description given are for general reference only and belts purchased by description and dimension generally will only provide temporary service.

**NOTE:** If mower fails to respond to speed control lever, it is possible that the variable speed pulley is seizing. Apply a few drops of light oil to each side of the assembly to loosen. Re-apply dry lubricant. Do not get lubricant on belts. It is not necessary to dismantle to apply lubricant.





**PARTS LIST FOR MODELS 136-430A AND 136-435A**


Ref. No.	Part No.	Color Code	Description	Ref. No.	Part No.	Color Code	Description	New Part
1	10426		Belt Keeper Ass'y.	40	712-0267		Hex Nut 5/16-18 Thd.*	
2	756-0232		Two Step Engine Pulley	41	736-0119		L-Wash. 5/16" Scr.*	
3	10438		Vari. Speed Pulley Ass'y.	42	710-0289		Hex Hd. Cap Scr. 1/4-20 x .50"	
4	736-0921		L-Wash. 1/2" Scr.*				L-Wash. 1/4" Scr.*	
5	712-0922		Hex Jam Nut 1/2-20" Thd.	43	736-0329		Hex Hd. Cap Scr. 1/4-28 x .62"	
6	756-0124		Pulley 4.75 O.D. (Deck)	44	710-0195		Hex Nut 5/16-18 Thd.*	
7	754-0127		V-Belt 21/32 x 66.0" Lg.	45	712-0267		L-Wash. 5/16" Scr.*	
8	712-0242		Hex Jam Nut 5/8-11 Thd. (Deck)	46	736-0119		Deck Reinforcement Plate	
9	736-0162		Flat Washer .641 I.D.	47	09164		Belt Guard (Deck)	
10	09321		Blade Spindle Ass'y.	48	09733		Ball Brg. .787 I.D. x 1.85 O.D.	
11	08253		Housing—Bearing	49	741-0919		Hex Sems Scr. 5/16-18 x 1.00"	
12	711-0255		Blade spindle	50	710-0322		Hex Hd. Cap scr. 3/8-24 x 1.00" Lg. H.T.	
13	714-0365		#6 Hi-Pro Key 5/32 x 5/8" Dia.	51	710-0152		L-Wash. 3/8" Scr. H.D.	
14	11237		Wheel Brkt. Ass'y. L.H. (Deck)	52	736-0217		Flat Wash. .406 I.D. x 1.25 O.D.	
15	09733		Belt Guard (Deck)	53	736-0235		Hex Hd. Cap Scr. 3/8-24 x 1.00" Lg. H.T.	
16	732-0153		Spring .750" O.D. x 8.65" Lg.	54	710-0152		L-Wash. 1/2" Scr.*	
17	12340		30 Inch Deck Ass'y.	55	736-0921		V-Belt 21/32 x 31" Lg. (For Transmission Pulley)	
18	712-0123		Hex Nut 5/16-24 Thd.*	56	754-0136		Split Transmission Pulley .50 I.D.	
19	736-0119		L-Wash. 5/16" Scr.*	57	756-0174		Hex Nut 5/16-18 Thd.*	
20	742-0118		15 Inch Blade	58	712-0267		L-Wash. 5/16" Scr.*	
21	710-0117		Hex Hd. Cap Scr. 5/16-24 x 1.00" Lg. H.T.	59	736-0119		V-Belt 21/32 x 25" Lg. (From Eng. Pulley to Var. Spd. Pulley)	
22	10769		Blade Adapter Kit	60	754-0135		Belt Guard Cup Ass'y. (For Eng. Pulley)	
23	710-0459		Hex Hd. Cap Scr. 3/8-24 x 1.50" Lg. H.T.	61	10424		Sheave Half	
24	10769		Blade Adapter Kit	62	748-0177		Spring Pin Spir. 5/32" Dia. x .62" Lg.	
25	726-0106		Push Nut 1/4" Rod	63	715-0124		Moveable Sheave Ass'y.	
26	711-0571		Pivot Pin	64	748-0181		Ball Brg. .50 I.D. x 1.38 O.D.	
27	732-0261		Torsion Spring	65	741-0139		Steel Tubing	
28	11399		Adapter Plate Ass'y.	66	750-0144		Spacer .520 I.D. x .692 O.D.	
29	726-0106		Push Nut 1/4" Rod	67	750-0146		Ball Brg. .50 I.D. x 1.38 O.D.	
30	11574		Chute Deflector Ass'y.	68	741-0139		Sheave Half	
31	738-0119		Shld. Scr. .625" Dia. x 1.75 (Axle Bolt)	69	748-0177		L-Wash. 3/8" Scr. H.D.	
32	712-0116		Hex Ins. L-Nut 3/8-24 Thd.	70	736-0217		Blade Brake Disc Ass'y.	
33	10937		Wheel Pivot Bar	71	11530		30" Deck Ass'y.—Comp.	
34	734-0295		5.0 Inch Wheel Ass'y. (Deck)	72	12347			
35	736-0105		Belleville Wash. .400 I.D. x .88 O.D.					
36	10949		Spring Lever Ass'y. with Knob					
37	11236		Wheel Brkt. Ass'y.—R.H.					
38	736-0119		L-Wash. 5/16" Scr.*					
39	712-0267		Hex Nut 5/16-18 Thd.*					

**WHEEL CHART**

**FRONT WHEEL**

**REAR WHEEL**

Part. No.	Description	Part. No.	Description
734-0483	Wheel Ass'y.—Comp.	734-0523	Wheel Ass'y.—Comp.
748-0184	Bearing	734-0517	Rim with Hub Ass'y.
		734-0298	Tire Only Tubeless 13 x 5.00
		734-0255	Air Valve
		—	Hub Part of Rim
		734-0249	Inner Tube (Service Only)



**BATTERY BOX BREAKDOWN**

**PARTS LIST FOR BATTERY BREAKDOWN MODELS 136-430A AND 136-435A**

Ref. No.	Part No.	Color Code	Description	New Part	Ref. No.	Part No.	Color Code	Description	New Part
1	735-0109		Stem Bumper		11	710-0252		Hex Hd. Cap Scr. 1/4-20 x .75" Lg.* (435A)	
2	10062 —462		Battery Box Bracket Ass'y.		12	725-0117		Battery Dry 12 Volt with Acid Pack (435A)	
3	10060 —462		Seat Bracket		13	710-0322		Hex Sems Scr. 5/16-18 x 1.00" Lg.*	
4	712-0267		Hex Nut 5/16-18 Thd.*		14	736-0119		Spring Lockwasher 5/16" Scr.*	
5	736-0159		Flat Washer .344 I.D. x .88 O.D.		15	712-0267		Hex Nut 5/16-18 Thd.*	
6	735-0127		Rubber Washer .33 I.D. x .87 O.D.		16	10059 —462		Battery Box	
7	710-0198		Hex Sems Scr. 5/16-18 x .75" Lg.*		17	710-0216		Hex Hd. Cap Scr. 3/8-16 x .75" Lg.*	
8	712-0287		Hex Nut 1/4-20 Thd.* (435A)		18	736-0169		Spring Lockwasher 3/8" Scr.*	
9	736-0329		Spring Lockwasher 1/4" Scr.* (435A)						
10	725-0150		Battery Ground Wire (435A)						


\*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

## DECK LINKAGE



### NOTE

Refer to illustration below for proper deck link hook-up. If the deck is removed for any reason use the illustration below for correct assembly.



# PARTS INFORMATION

## POWER EQUIPMENT PARTS AND SERVICE

Parts and service for all MTD manufactured power equipment are available through the authorized service firms listed below. All orders should specify the model number of your unit, parts numbers, description of parts and the quantity of each part required.

<b>ALABAMA</b>	<b>BIRMINGHAM</b>	
Auto Electric & Corburetor Co.	2625 4th Ave. S.	35233
<b>ARKANSAS</b>	<b>NORTH LITTLE ROCK</b>	
Sutton's Lawn Mower Shop	Rt. 4, Box 368	72117
	<b>FORT SMITH</b>	
Mity Mite Motors, Inc.	2515 Towson Ave.	72901
<b>CALIFORNIA</b>	<b>SAN BERNARDINO</b>	
Lawn Mower Supply Co.	25608 E. Boseline	92410
	<b>SAN FRANCISCO</b>	
J.W. Jewett Co.	981 Folsom St.	94107
	<b>SACRAMENTO</b>	
Luttig & Severson	2030 28th St.	95818
<b>COLORADO</b>	<b>DENVER</b>	
South Denver Lawn Equip.	527 West Evans	80223
<b>CONNECTICUT</b>	<b>SUFFIELD</b>	
The Jones & Romsey Co.	850 Thompsonville Rd.	06078
<b>FLORIDA</b>	<b>JACKSONVILLE</b>	
Rodco Distributors	2403 Market St.	32206
	<b>CORAL GABLES</b>	
Moz-All of Florida, Inc.	365 Greco Ave.	33146
<b>GEORGIA</b>	<b>EAST POINT</b>	
East Point Cycle & Key	2834 Church St.	30344
<b>ILLINOIS</b>	<b>LYONS</b>	
Keen Edge Co.	8615 Ogden Ave.	60534
<b>INDIANA</b>	<b>ELKHART</b>	
Ports & Soles Inc.	2101 Industrial Pkwy.	46514
	<b>CORYDON</b>	
Brown Equip. Dist., Inc.	110 Beech St.	47112
<b>IOWA</b>	<b>DUBUQUE</b>	
Power Lawn & Garden Equip.	2551 J.F. Kennedy	52001
<b>KANSAS</b>	<b>WICHITA</b>	
Hixon, Inc.	3030 Moscot	67204
<b>LOUISIANA</b>	<b>NEW ORLEANS</b>	
Suhren Engine Co.	8330 Eorhort Blvd.	70118
<b>MARYLAND</b>	<b>TAKOMA PARK</b>	
Center Supply Co.	6867 New Hampshire Ave.	20012
<b>MASSACHUSETTS</b>	<b>SPRINGFIELD</b>	
Morton B. Collins Co.	300 Birnie Ave.	01107
<b>MICHIGAN</b>	<b>MOUNT CLEMENS</b>	
Power Equipment Dist.	36463 South Grotiot	48043
	<b>LANSING</b>	
Lorenz Service Co.	2500 S. Pennsylvonio	48900
<b>MINNESOTA</b>	<b>MINNETONKA</b>	
Honce Distributing Inc.	11212 Woyzoto Blvd.	55343
<b>MISSISSIPPI</b>	<b>BILOXI</b>	
Biloxi Soles & Service, Inc.	506 Coillovet St.	39533
<b>MISSOURI</b>	<b>KANSAS CITY</b>	
Automotive Equip. Service	3117 Holmes St.	64109
	<b>ST. LOUIS</b>	
Henzler, Inc.	2015 Lemoy Ferry Rd.	63125
<b>NEBRASKA</b>	<b>OMAHA</b>	
R.P.W., Inc.	7402 "L" St.	68127

## BRIGGS & STRATTON, TECUMSEH AND PEERLESS PARTS AND SERVICE

Briggs & Stratton, Tecumseh and Peerless parts or service should be handled by your nearest authorized engine service firm. Check the yellow pages of your telephone directory under the listing *Engines Gasoline*, Briggs & Stratton or Tecumseh Lauson

<b>NEW YORK</b>	<b>CARTHAGE</b>	
Gomble Dist., Inc.	West End Ave.	13619
	<b>SYRACUSE</b>	
Kimber's, Inc.	115 N. Geddes St.	13204
	<b>ROCHESTER</b>	
Henry W. O'Neil & Associates	410 N. Goodman St.	14609
<b>NORTH CAROLINA</b>	<b>GREENSBORO</b>	
Dixie Soles Company	327 Bottleground Ave.	27402
	<b>GOLDSBORO</b>	
Smith Hordware Co.	515 N. George St.	27530
<b>OHIO</b>	<b>WADSWORTH</b>	
Notional Control	687 Seville Rd.	44281
	<b>CLEVELAND</b>	
Bleckrie, Inc.	7900 Lorain Ave.	44102
	<b>CARROL</b>	
Stebe's Mid-Stote Mower Supply Box	366	43112
	<b>WILLARD</b>	
Sunshine Wholesale Tire Outlet	Route 224	44890
	<b>MANSFIELD</b>	
McClure Lawn & Garden Supply	1114 Lexington Ave.	44903
<b>OKLAHOMA</b>	<b>MUSKOGEE</b>	
Victory Motors, Inc.	605 S. Cherokee	74401
	<b>ADA</b>	
Ado Auto Supply	301 E. 12th St.	74820
<b>OREGON</b>	<b>PORTLAND</b>	
Kenton Supply Co.	8216 N. Denver Ave.	97217
<b>PENNSYLVANIA</b>	<b>LANCASTER</b>	
Roub Supply Co.	James & Mulberry Sts.	17604
	<b>PITTSBURGH</b>	
Bluemont Co.	11125 Frankstown Rd.	1523
<b>TENNESSEE</b>	<b>KNOXVILLE</b>	
Moster Repoir Service	2423 Broadway, N.E.	37917
	<b>MEMPHIS</b>	
Memphis Cycle & Supply Co.	421 Monroe Ave.	38103
Americon Soles & Service, Inc.	1922 Lynnbrook	38117
<b>TEXAS</b>	<b>DALLAS</b>	
Morr Brothers, Inc.	423 E. Jefferson	75203
	<b>HOUSTON</b>	
Bullord Supply Co.	2409 Commerce St.	77003
	<b>SAN ANTONIO</b>	
Cotto & Putty, Inc.	P.O. Box 2408	78206
	<b>FORT WORTH</b>	
Woodson Soles Corp.	1702 N. Sylvonio	76111
<b>UTAH</b>	<b>SALT LAKE CITY</b>	
A-1 Engine & Mower Co.	437 E. 9th St.	84111
<b>VERMONT</b>	<b>BURLINGTON</b>	
Vermont Applience Co.	44 Lakeside Ave.	05401
<b>VIRGINIA</b>	<b>RICHMOND</b>	
RBI Corp.	963 Myers St.	23260
<b>WASHINGTON</b>	<b>SEATTLE</b>	
Boiley's Rebuild, Inc.	1325 E. Modison St.	98102
<b>WEST VIRGINIA</b>	<b>CHARLESTON</b>	
Young's, Inc.	233 Virginio St., E.	25301
<b>WISCONSIN</b>	<b>APPLETON</b>	
Automotive Supply Co.	123 S. Linwood Ave.	54911

## WARRANTY PARTS AND SERVICE POLICY

The purpose of warranty is to protect the customer from defects in workmanship and materials, defects which are NOT detected at the time of manufacture. It does not provide for the unlimited and unrestricted replacement of parts. Use and maintenance are the responsibility of the customer. The manufacturer cannot assume responsibility for conditions over which it has no control. Simply put, if it's the manufacturer's fault, it's the manufacturer's responsibility; if it's the customer's fault, it's the customer's responsibility.

### CLAIMS AGAINST THE MANUFACTURER'S WARRANTY INCLUDES

1. Replacement of Missing Parts on new equipment.
2. Replacement of Defective Parts within the warranty period.
3. Repair of Defects within the warranty period.

All claims MUST be substantiated with the following information:

1. Model Number of unit involved.
2. Date unit was purchased or first put into service.
3. Date of failure.
4. Nature of failure.